

SLX H19 (542.000-572.000 MHz)

CHANNEL	Group 1	Group 2	Group 3	Group 4	Group 5	Group 6	Group 7
	Full Range		Full Range - max , of freqs for TV CH-26	Full Range - max , of freqs for TV CH-27	Full Range - max , of freqs for TV CH-28	Full Range - max , of freqs for TV CH-29	Full Range - max , of freqs for TV CH-30
1	543.200	542.350	542.275	548.250	554.275	560.250	566.250
2	544.525	546.400	543.725	549.700	555.700	561.500	567.725
3	546.650	549.550	544.850	550.800	556.800	563.175	568.825
4	548.125	551.700	546.450	552.425	558.375	564.275	570.500
5	549.250	555.000	547.725	553.700	559.625	565.775	571.750
6	556.375	557.325	552.175	543.500	543.350	542.450	543.375
7	559.175	564.150	555.425	557.400	544.475	544.100	545.200
8	560.825	565.475	561.500	560.425	551.275	545.450	550.050
9	563.125	567.125	563.425	562.000	552.550	551.075	553.250
10	564.950	569.100	566.500	564.325	565.950	555.225	555.400
11	568.750	570.575	568.250	566.250	568.650	568.900	559.100
12	571.200	571.675	570.325	569.600	570.625	570.350	564.250